

# MANN-FILTER

## Product Information

No. 119  
28.08.2015

### Mounting instruction for oil filter elements with a center tube without intubation-bevel

e. g. HU 721/4 x, HU 815/2 x

Because of the fact, that the center tube of the housing cover for the oil filter elements HU 721/4 x and HU 815/2 x does not have any intubation-bevel at the sealing seat, the sealing surface of the element has to be pushed over an edge. For that, a higher effort is required.

The mounting of the element is good feasible, if below mentioned steps will be followed:

1. Fix the oil filter element oblique at the edge (red marked) of the center tube.



2. Rotate the element and slide it on the center tube of the housing cover afterwards.



3. Finally, push the element up to the stop in the housing cover, that the two sealing surfaces of the element fit correctly on the center tube.

